Due to regular testing requirements, installation of a System Testing point is recommended. This is a break in the activation cable from the control panel. Attach Deutsch plugs which allow the FirePro Simulator to be connected. Locate where it is easy to access and be labelled as **"Fire System Test Point".** **The benefit is that all FirePro units in the system will be disconnected for testing, so the chance of accidental activation during testing is reduced.** It creates a process which is easy to follow for anyone working on the system.

TEST POINT

Activation Cable from Panel

Suits
FP-08450
FP-08451
Control Panels

Locate TEST POINT where easy to access.

Label TEST POINT

Connection of the FirePro Test Module at the test point disconnects all downstream units.

Activation Wiring Circuit

Extension Lead

Splitter Lead

Deutsch Plug 3 Pin Male/Female

A B

A - Active (Red)
B - Neutral (Black)
C - Earth/Shield

C

FP Unit 1
FP Unit 2
FP Unit 3
FP Unit 4