

# **FP-22408**

# & 17310 Fire Control Panel Operation and Maintenance Manual

## **Table of Contents**

1.	Introduction		2
2.	Operation		2
3.	Installation	Procedure	3
	3.1. 3.2. 3.3. 3.4. 3.5. 3.6. 3.7. 3.8. 3.9. 2.10	Installation and Mounting Power Supply – Connect directly to Battery Manual Activation Switches Linear Heat Detection Cable Installation of FirePro Units – MAX 4 Units Thermal Fuse Relay Connections and Programming Sounder circuit wiring Extension Leads	3344556666
4. Panel Operation		ration	7
5	4.1. 4.2. Maintenan	Silence Alarms Isolation Mode	7 7 7
5.	5.1. 5.2.	TroubleShooting & Fault Codes Replacing the Internal Battery	, 7 7
6.	Commissioning & Testing		8
7.	Component Description		9
8.	Specifications		9

### 1. Introduction

The Model 22408 vehicle control panel to provide an integrated fire detection and suppression system. This control panel allows up to 4 FirePro Generators of any size to be installed. The panel is compliant to AS5062.

The FIP (fire indicator panel) incorporates-

- two monitored detection circuits,
- a monitored activation circuit,
- a monitored power supply circuit with installed 10A fuse
- a monitored 24hr backup battery circuit with battery installed.
- programmable shutdown delay time.

# 2. Operation

### **IN CASE OF FIRE**

The FirePro Vehicle Suppression System is an automatic system and has Manual switches. In case of fire follow these steps:

- 1. The Detection system will activate suppression system automatically in case of fire.
- 2. Safely Stop the Vehicle and Evacuate all personnel from the vehicle as soon as possible.
- 3. Where manual activation required Remove Travel Pin from Activation Switch and press switch.
- 4. Keep the FirePro Aerosol within the risk until the fire is completely extinguished or fire may reignite.
- 5. Wait approximately 20min for the FirePro Aerosol to dissipate and clean up with soapy water.
- 6. DO NOT open the risk area or attempt to restart the engine, until the fire is completely extinguished and the machine has sufficiently cooled.
- **7.** System will remain in fault until the FirePro generators are replaced.

**SYSTEM OK INDICATOR** will indicate green, when the system is receiving appropriate 24vDC supply and is operating normally. If power is not supplied, or a fault if detected the LED will not be lit and the panel will not operate or function correctly.

FIRE INDICATOR will indicate red when the detectors go into alarm or a manual activation switch is pressed.

**RELAY RESET INDICATOR** and Button. Pressing the button will interrupt the programmed shutdown. This delay can be maintained by continuously pressing the button. - indicates that the relay time delay has been reset. If the system is in an alarm condition and has been serviced/recharged, the reset button will allow for normal vehicle operation.

**ALARM SILENCE INDICATOR** and Button - will indicate amber when the alarm has been silenced. if pressed, the alarm will silence for 6 hours before sounding again. All other Fault lights will continue to indicate that a problem is present.

**SERVICE SYSTEM INDICATOR** - will indicate amber, and activate an alarm, to show that a fault is present. LED will flash in a numbered sequence to indicate which circuit is experiencing a fault (see Fault Codes).

**PUSH TO TEST** Button - Allows the operator to check functionality of all LED's, relays and alarms without activating the system.

**ISOLATION MODE** - Pressing the Amerex Logo button five times will put the panel into *Isolation Mode*. To deactivate Isolation Mode – Press and Hold the Amerex Logo Button for 5 seconds.(only for model 22408)

### **3. Installation Procedure**

#### 3.1. Installation and Mounting

Mount the Amerex 22408 Control Panel in a dry, protected area (such as inside the vehicle cab). It should be clearly visible and within reach of the vehicle operator.

#### DIMENSIONS - 135H x 189W x 50D mm



Connect the wiring loom to the panel. Note: each cable uses a different plug to ensure that they are connected to the correct plug. DO NOT force plugs.

The panel should not be placed in

environments where the temperature is outside the range of -40°C to +66°C.

Mounting Bracket (FP-22408B) may be used. This bracket will accommodate the control panel and a manual activation switch. Made from 316 stainless steel.



()	Fire Suppression Control Panel		$\bigcirc$ $\textcircled{1}$
$\oplus$ $\bigcirc$	Relay Reset Push to Test Service System	Alarm Reset	⊕ ()



#### 3.2. **Power Supply – Connect directly to Battery**

Connect Power Supply Assembly to the vehicle's battery terminals and connect to panel using the Power Supply lead coming from the panel (marked Red). **Note:** the Red cable goes to the battery's positive terminal and the black cable goes to the battery's negative terminal.



#### 3.3. Manual Activation Switches

Mount the Internal Activation Switch in a dry, protected area (such as the vehicle cab). It should be clearly visible and within reach of the vehicle operator. This should then be connected to the control panel using one of the two Detection Circuits (marked Green).



Mount the External Activation Switch on the exterior of the vehicle. This should be easily accessible and away from the risk area. **Note:** the supplied End of Line module MUST be plugged into the cables coming out of the Internal Activation Switch if no External Activation Switch is to be used.





Switch Shown in External Mount

Switch mechanism with travel Pin

#### 3.4. Linear Heat Detection Cable

Mount the Linear Heat Detection Cable inside the risk area using the supplied P-clips every 500mm and junction boxes. With reference to use one of the supplied 2 Pin Deutsch Plug pairs create a extension cable and plug into the remining Detection Circuit (marked Green). This kit comes with an installed End Of line resistor that must be installed at the end of the LHD cable. **Note:** wiring should not be done in a way that place tension on the cable and installers MUST observe the minimum bend radius on 150mm.



#### 3.5. Installation of FirePro Units – MAX 4 Units

Using the supplied Heavy Duty Brackets, mount the FirePro Generators inside the risk area facing engine components that pose hazards in case of fire (for example; turbo, fuel supply and battery). Connect the FirePro generator(s) to the panel using the Activation Circuit (marked Yellow). For risks that require two or more FirePro generators use the supplied splitter cable(s).



#### 3.6. **Thermal Fuse**

Using the supplied Thermal Fuse, remove the cap on the thermal port on one FirePro generator (see image). Screw thermal fuse into thermal port and connect cable to the System Discharge Advice circuit coming from the control panel (marked Blue).



#### 3.7. **Relay Connections and Programming**

The control panel also provides a Shutdown/Warning Relay to shutdown the vehicle's engine and activate any auxiliary warning equipment (for example sirens or lights).

The colour code for the relay wiring is: Common-Red

Normally Closed-Black

Normally Open-White.

Any device that is wired to the relay must draw its own current from an independent power lead with a 5 Amp AGC fast blow fuse. One of the supplied 3 Pin Deutsch Plugs is supplied any connection.

#### **RELAY PROGRAMMING**

The delay for the activation of the shutdown relay can be programmed from 0 to 15 seconds (in 5 second intervals). The default time delay is 15 seconds. To program :

Press and hold the "Relay Reset" and "Alarm Service" buttons simultaneously for 20 seconds.

The panel will chirp once and the "System OK" LED will flash.

Press the "Relay Reset" button "x" times for the desired relay delay.

After 10 sec has elapsed, the panel will chirp twice and the "System OK" LED will stop flashing.

No. times the Button is	Seconds Of
pressed	Delay
1	0
2	5
3	10
4	15

#### 3.8. Sounder circuit wiring

There is no dedicated Siren circuit on this panel. Using the Relay a siren can be connected.

#### 3.9. **Extension Leads**

Each FirePro Vehicle Suppression System is supplied with 10 metres of Shielded, 2 hour Fire Rated, 2 Core Cable,  $4 \times 2$  Pin Deutsch Plug Pairs and  $3 \times 3$  Pin Deutsch Plug Pairs. These MUST be used for the construction of any extension lead. If additional cable or Deutsch plugs are required this needs to be specified by the installer. To create extension leads follow these steps:

- 1. Cut cable to required length and strip outer insulation to approximately 50mm. Remove shielding and for 2 Pin plugs cut earth off.
- 2. Strip inner insulation to approximately 6mm and using an approved Deutsch Crimping tool, fix pins to the exposed ends of the cable. For 3 Pin plugs this includes the earth.
- 3. Place heat shrink or rubber boot over the end of the cable. Ensuring that pins are securely fixed to the cable, identify correct socket on plug by noting the numbers or letter on the side of the plug and push through the gasket at the bottom of the plug until a click is heard and the pin is locked in place.
- 4. Place the locking wedge inside the plug to ensure pins remain secure. For male plugs the locking wedge is orange and for the female plugs it is green.
- 5. Using the heat shrink, rubber boot, or other approved insulation, seal the back of the plug and using one of the supplied cable ties mark the cable to identify which circuit it will be used.



#### 3.10. Colour Coded Cables

Cables are colour coded for easy identification. When installing system, cables should be only connected to the correctly coded cable. Colour Coding for cables is as follows:

Colour		Circuit
	Red	Power
	Yellow	Activation
	Green	Detection
	Blue	Thermal Fuse

### 4. Panel Operation

#### 4.1. Silence Alarms

In the event of a system alarm or system service the audible alarm can be silenced with the "Alarm Silence" button. When the "Alarm Silence" button is depressed, the "Alarm Silence" LED will illuminate and the other LEDs will continue to show the alarm or service system fault status. The alarm will remain silent for 6 hours and will then resound to remind personnel that a problem condition is present.

#### 4.2. **Isolation Mode**

Model 22408 ONLY. Pressing the Amerex Logo button five times will put the panel into *Isolation Mode*. During isolation mode the following panel conditions will be in effect:

- The green System OK LED <u>will blink continuously</u> indicating the panel has power but is in isolation mode. The <u>Amber</u> colored Service System LED will <u>stay steady on</u>. The audible alarm will chirp every 30 seconds to indicate the panel is in isolation mode.
- In isolation mode the firing circuit is disabled. All other circuits, (detection, pressure switch, relay) remain operational. Isolation mode can be used for testing, transportation, machine maintenance etc.
- In isolation mode if either detection circuit is activated the red FIRE LED will illuminate, the audible alarm will sound and the relay will begin countdown. This condition would remain until the source of the alarm is cleared.
- The panel will remain in isolation mode until mode is deactivated.
- **To deactivate mode**, insure the red FIRE LED is not illuminated, press and hold the Amerex Logo button for five seconds. Panel returns to normal mode green LED System OK illuminated unless fault condition are present. If fault conditions are present, panel flashes standard fault codes at the Service System LED.
- Relay Transfer (engine shutdown) is indicated by <u>a RED LED</u> at the Relay Reset Button.

To Isolate the Model 17310 panel simply unplug the activation cable – and this will put the panel into fault. This should be done at the connection closest to the panel.

### **5. Maintenance**

Control panels do not require any specific maintenance but should the control panel become dirty it can be wiped over with a damp cloth and should then be dried with a dry, lint free cloth. Detergents or solvents should not be used to clean the panel and care must be taken that water does not *Enter* the enclosure.

Testing of the extinguishant system should only be carried out by trained personnel and must be done with appropriate isolation measures in place to ensure that accidental discharge of the extinguishant agent is avoided and any malfunction should be reported to the fire alarm maintenance company immediately.

#### 5.1. TroubleShooting & Fault Codes

In the event of a system fault in any of the supervised circuits, an audible alarm will sound and the yellow "Service System" LED will flash once every ten seconds in a coded sequence to indicate the circuit presenting with a fault.

If a fault is detected there is a five second delay before notification. For power supply faults, the delay for notification is 20 seconds.

The audible alarm can be silenced with the "Alarm Silence" button. When pressed, the "Alarm Silence" LED will illuminate and the other Fault LEDs will remain on. The alarm will remain silent for 6 hours and will then resound to remind personnel that a fault condition is present.

Fault Source	No. LED Flashes
Power Supply	1
Detection Zone 1	2
Detection Zone 2	3
Activation Circuit	4
Backup Battery	5
Thermal Fuse	7

#### 5.2. **Replacing the Internal Battery**

This battery should be **replaced every 2 years** to ensure proper system function or if the panel indicates that there is a fault in the backup circuit. To replace:

- 1. Remove the four screws on the front of the panel to remove the front cover.
- 2. Disconnect the battery connector and remove old battery.
- 3. Replace battery (P/N 18156).
- 4. Reconnect the battery and replace the front cover.
- 5. Check the "Service System" LED on the front of the panel. If installed correctly, there will be no fault.



### 6. Commissioning & Testing

**IMPORTANT** : Before testing or commissioning, FirePro generators should be physically isolated from the system. This is achieved by unplugging the activation cable (marked Yellow) and plugging in the test module. This will prevent any accidental release of extinguishant.

To ensure that your FirePro system will operate as designed, it should be inspected and serviced every 6 months in accordance with AS1851 and AS5062.

- 1. Unplug the FirePro Generator(s) and plug in the Test Module. Control Panel should display "System OK".
- 2. Clean the Control Panel and components to remove dirt, grease and foreign material. Replace any parts that appear damaged or are painted.
- 3. Inspect all wiring connections are tight and sealed from the weather and check for any wire fatigue.
- 4. Inspect FirePro Generators and brackets are free from debris and any corrosion. Ensure brackets are tight and show no signs of fatigue.
- 5. Inspect Linear Heat Detection Cable ensuring it maintains a closed connection and check cable for kinks, bends, etc. Replace cable if necessary.
- 6. To test the linear heat detection circuit, bridge out the connection in the LHD junction box and ensure that panel activates the Test Module.
- 7. Inspect condition of Manual Activation Switches. Check each switch by pressing and releasing. The Panel should go into alarm when each switch is pressed.
- 8. Inspect connection of the relay and test to ensure it operates as desired.
- 9. Unplug the Test Module and plug in the FirePro Generator(s). Control Panel should display "System OK".

### LOGBOOK

The installation should be maintained by an accredited person and a logbook must be kept, recording all the relevant events concerning the installation. The logbook contains the items required by Australian Standards for the life of the installation.

Content of logbook:	
🗆 General details & Risk Assessment	Comments re outcome of each inspection
Devices used	□ Schematic diagrams
Date of each Inspection	Photos of the Original FirePro Installation

### 7. Component Description











100g – 500g Unit. Constructed from Stainless Steel. Comes with installed Deutsch Plug for easy install.

Signage for the System. A sheet of

Linear Heat Detection Cable 182° C

2 Hour Fire Rated Shielded Cable.



backup battery. Features: - Automatic or Manual Activation.

- Monitors all electrical circuits.





#### FP-6200

FP-22408 Amerex AS5062 Vehicle Control Panel

- Fires up to 4 FirePro Aerosol Generators.

Operates on 10vDC-30vDC power supply with integrated 24hr

- 2x Detection Circuits; 1x Programmable Shutdown Relay.

- Vibration and weather proof and EMI/RFI resistant.

Heavy Duty Bracket 316 SS. Suits FP-100, 200, 500 FirePro Aerosol Generators.

#### FP-08826

Thermal Fuse Constructed from Stainless Steel.

#### FP-09511

Linear Heat Detection Installation kit. Mounting Clips, 2x Junction Boxes with strain relief cable glands and 1x EOL for monitoring.

#### FP-14016

Battery Lead



FP-08912

FP-09500

FP-08960

FP-09510

different size labels.

Wiring loom and Splitter Cable for installaion of multiple FirePro generators.



FP-08800

FirePro Simulator – for Testing & Commissioning.

## 8. Specifications

-			
Mains supply	12 – 24v DC		
Battery	24 hours of Fire Suppression Capability - Nickel Metal Hydride (NiMH)		
Current Requirements			
Normal Operations	12v DC – 18mA	24v DC – 47mA	
Fault Condition	12v DC – 10-18mA	24v DC – 47-52mA	
Alarm Condition	12v DC – 66mA	24v DC – 78mA	
Extinguishant release	Immediate – Max 4 FirePro Aerosol units		
Temperature	Temperature Range -40°C to +66°C		
Audible Alarm – Built in	Output-Continuous Signal - 85dB @ 36" - Resonant Frequency: 2800 Hz continuous		
Detection Type	Latching Type NO – LHD Cable		
Detection Circuit End of Line	2K2 resistor		
Fault relay contact rating	30VDC 1A Amp max		
Fire relay contact rating	30VDC 1A Amp max		
Dimensions	109mm x 77mm x 38mm – Weight :590g		

Commissioning Information	
Customer	
Vehicle Make / Model	
Vehicle ID Number	
Date of Installation	
FirePro Units Installed	Specify Size and No of units
Manual Activation	Specify Location of Manual Actuation Switches
Shutdown Installation	Specify Delay Time and Shutdown Details
Other Information	Any other information relevant to this installation