Detection & Activation System

- Power
- Circuit 1 Alarm
- Circuit 2 Alarm
- Fault
- Isolated
- Discharging
- Agent Released

Press both buttons for 5 seconds for discharge

Press and hold single button
1 beep - Isolate | 2 beeps - Reset | 3 beeps - Test
FirePro. FP-08451

Features

The FIP (fire indicator panel) incorporates:

- 2x Detection circuits;
- 1x Extinguishing Discharge circuit;
- 1x Siren/Strobe circuit;
- 1x Agent Release Notification circuit;
- Programmable Activation (automatic and/or manual);
- Fault Monitoring system;
- Isolation Function.
- Cable loom uses Deutsch plugs for "plug and Play" installation.
- Cables are colour coded for easy identification.

Certified Product - AS 5062
Global-Mark.com.au®
ID Number: 103334

General Information

The FirePro FP-08451 Fire Control Panel is a combined detection and extinguishant system, and is compliant for use in both marine (AMSA NSCV) and vehicle installations (AS5062).

The FP-08451 Control Panel provides a comprehensive fault monitoring system that will detect faults in the detection, activation, and siren circuits, and any malfunctions of the control panel's internal components.

Modules are available to allow for: extended or delayed system discharge or shutdown of devices.

Specifications

Dimensions	148L x 84W x 35D mm
Material	Diecast Aluminium, UV Tolerant
Ingress Protection	IP65
Operating Temp.	-40 to 85 degrees Celsius
Power	12-30VDC

Detection Zones	2
Detectors per Zone	Max 30 Conventional Detectors Max 30 Manual Actuators
Agent Release	Thermal >80°C , NC, Non-resettable
Siren Strobe	Max 0.5A